MONRO-JET®

Orbital-nozzle

Spare parts list



1. NOZZLE BODY F3	ART. NR.
	10341

7. INLET COVER	ART. NR.	CONNECTION THREAD
	11505	1/4" BSP
	11503	1/2" BSP
	11504	1/2" NPT
	11502	3/8" BSP
	11501	3/8" NPT
6. O-Ring D28 x 2 for inlet cover	10274	---

8. CONNECTION THREAD SEAL		
ART. NR.	DESCRIPTION	INLET COVER
10273	O-Ring Ø15x2	1/2" BSP
10273	O-Ring Ø15x2	1/2" NPT
10273	O-Ring Ø15x2	3/8" BSP
10273	O-Ring Ø15x2	3/8" NPT

mvt micro technologies

mvt AG | Spärsstrasse 5 | Postfach | CH - 2562 Port
T +41 32 332 97 60 | F +41 32 332 97 61 | info@mvt.ch

www.mvt.ch

3. REPAIR KIT TYPE F3

ART. NR.	ROTOR Ø
31518	0.60
31514	0.65
31519	0.70
31540	0.75
31513	0.80
31509	0.85
31520	0.90
31532	0.95
31521	1.00
31531	1.05
31541	1.10
31530	1.15
31523	1.20
31496	1.25
31566	1.30
31536	1.35
31526	1.40
31528	1.45
31527	1.50
31499	1.55
31512	1.60
31544	1.65
31567	1.70
31558	1.75
31534	1.80
31684	1.85
31535	1.90
31542	1.95
31557	2.00
31577	2.05
31674	2.10
31600	2.15
31703	2.20
32040	2.25
31691	2.30
XXXX	2.35
32036	2.40
XXXX	2.45
31678	2.50
XXXX	2.55
31633	2.60
XXXX	2.65
32059	2.70
XXXX	2.75
31579	2.80
2. O-Ring D7.1 X 1.6 for repair kit	10271	---

4. DRIVING TUBE

ART. NR.	DRIVING TUBE Ø	NUMBER OF BORES
11526	0.60	2
11527	0.65	2
11528	0.70	2
10371	0.75	2
10372	0.80	2
10373	1.00	2
10374	1.20	2
10375	1.40	2
10376	1.80	2
10377	2.40	2
10378	2.60	2
10379	2.80	2
10380	3.00	2
10381	3.20	2
10382	3.00	4
10383	3.20	4
10384	3.50	4
5. O-Ring D14 x 2 for driving tube	10272	---	---

Accessories:

MOUNTING TOOL

ART. NR.
10269

mvt AG | Spärsstrasse 5 | Postfach | CH - 2562 Port
T +41 32 332 97 60 | F +41 32 332 97 61 | info@mvt.ch
www.mvt.ch